



## Couplings


### SKF Flex couplings (Tyre)



### SKF Flex couplings (Flange)



### SKF Flex couplings (Spacer)



## Couplings

### SKF FRC couplings

Example: **PHE** **FRC70FTB**

SKF Prefix

FRC	Coupling type
70	Coupling size
RSB	Pilot bore hub type B (also called rough stock bore)
FTB	Tapered bushed hub type F (face)
HTB	Tapered bushed hub type H (hub)
NR	Standard element
FR	F.R.A.S element

### SKF jaw couplings / SKF Jaw spacer couplings


Example: **PHE** **L050HUB-18MM**

SKF Prefix


L	Coupling type
050	Coupling size
HUB	Hub type L
NR	Nitrile standard element
NRWRAP	Nitrile wrap element
UR	Urethane element
HL	Hydred element
RINGKIT	Ringkit
X100SPACER	Spacer 100 mm (only valid for SKF Jaw spacer coupling)
X140SPACER	Spacer 140 mm (only valid for SKF Jaw spacer coupling)
18MM	Bore to size and keywayed hubs with e.g. 18 mm bore (only if applicable)
16MMP	Bore to sized hubs (no keyway) with e.g. 16 mm bore (only if applicable)

## Couplings

### SKF gear couplings




### SKF grid couplings



## Couplings

### SKF chain couplings



### SKF universal joints

